


TEA POT WITH LID

P 6936/L 1.23 ltr. (43.12 oz.) 763 g.

TEA POT WITH LID

P 6937/L 0.55 ltr. (19.36 oz.) 446 g.



ROUND DINNER PLATE

P 6917 30.5 cm. (12") 1,065 g.

P 6918 28.0 cm. (11 1/8") 960 g.


P 6919 26.0 cm. (10 1/4") 742 g.



CREAMER

P 6938 0.15 ltr. (5.28 oz.) 180 g.

P 6939 0.30 ltr. (10.56 oz.) 274 g.




ROUND DESSERT PLATE

P 6920 23.0 cm. (9 1/8") 585 g.



SUGAR BOWL/BOULLION WITH LID

P 6940/L 0.27 ltr. (9.68 oz.) 433 g.



ROUND SIDE PLATE


P 6921 16.0 cm. (6 1/4" x 6 1/4") 255 g.



ROUND SAUCE JUG

P 6941 0.21 ltr. (7.56 oz.) 195 g.

P 6942 0.35 ltr. (12.32 oz.) 293 g.



ROUND LARGE DEEP PASTA PLATE

P 6922 28.00 cm. (11 1/8") 990 g.

ROUND DEEP PASTA PLATE

P 6923 22.5 cm. (8 7/8") 545 g.



COFFEE CUP

P 6929 0.32 ltr. (11.44 oz) 289 g.

COFFEE CUP SAUCER

P 6930 17.0 cm. (6 3/4") 278 g.

ROUND SOUP / CEREAL BOWL

P 6924 16.00 cm. (6 1/4") 505 g.



COFFEE CUP

P 6931 0.23 ltr. (8.27 oz) 222 g.

COFFEE CUP SAUCER

P 6933 16.0 cm. (6 1/4") 228 g.

ROUND FRUIT BOWL

P 6925 13.50 cm. (5") 246 g.



STACKING CUP

P 6932 0.27 ltr. (9.32 oz) 245 g.

COFFEE CUP SAUCER

P 6933 16.0 cm. (6 1/4") 228 g.

ROUND RICE BOWL

P 6926 11.50 cm. (4 1/2") 162 g.



ESPRESSO CUP

P 6934 0.11 ltr. (4.05 oz) 110 g.

ESPRESSO CUP SAUCER

P 6935 12.0 cm. (4 3/4") 135 g.



MUG

P 6927 0.41 ltr. (14.43 oz) 340 g.



STACKING MUG

P 6928 0.37 ltr. (13.02 oz) 340 g.



I k o n

Items and Description

